



- IP67/66 & Type 4/4X/13
- -40°C to +66°C (-40°F to +151°F)
- 1.5Kg (3.3lb);
- CE, EAC & Russian Maritime Register approved



Unit Type Code	Nominal Voltage	Voltage Range	Nominal Current
MBX05DC012	12 Vdc	10-14Vdc	750mA
MBX10DC012			1450mA
MBX05DC024	24 Vdc	20-28 Vdc	270mA
MBX10DC024			660mA
MBX05DC048	48 Vdc	42-54 Vdc	180mA
MBX10DC048			340mA
MBX05AC115	115 Vac	115 Vac ±10% 50/60Hz	140mA
MBX10AC115			250mA
MBX05AC230	230 Vac	230 Vac ±10% 50/60Hz	55mA
MBX10AC230			110mA



Use suitable conduit or cable glands with suitable IP or type rating

Attention: Installation must be carried out by an electrician in compliance with the latest codes and regulations.

Attention: L'installation doit être effectuée par un électricien conformément aux derniers codes et réglementations.

Achtung: Die Installation muss von einem Elektriker gemäß den neuesten Vorschriften und Bestimmungen durchgeführt werden.

Attenzione: L'installazione deve essere eseguita da un elettricista in conformità con i codici e le normative più recenti.

Atención: La instalación debe ser realizada por un electricista de acuerdo con los últimos códigos y regulaciones.

Atenção: A instalação deve ser realizada por um eletricista de acordo com os códigos e regulamentos mais recentes.

Внимание: установка должна выполняться электриком в соответствии с последними нормами и правилами.

Attention: Disconnect from power source before installation or service to prevent electric shock

Attention: Débranchez-le de la source d'alimentation avant l'installation ou l'entretien pour éviter tout choc électrique.

Achtung: Vor Installation oder Wartung von der Stromquelle trennen, um einen Stromschlag zu vermeiden.

Attenzione: scollegare dall'alimentazione prima dell'installazione o dell'assistenza per evitare scosse elettriche.


Atención: desconéctelo de la fuente de alimentación antes de la instalación o el servicio para evitar descargas eléctricas.

Atenção: Desconecte da fonte de alimentação antes da instalação ou serviço para evitar choque elétrico

Внимание: отключите от источника питания перед установкой или обслуживанием, чтобы предотвратить поражение электрическим током.

AC

See D207-06-205



DC

See D207-06-201

